



Parts List for DCE150B Type 1

Item Number	Part Number	Description	Qty Required
1	N421915	HANDLE SET	1
2	N458161	RATING LABEL	1
4	N421969	SWITCH & MODULE	1
5	N073265	FOR/REV SELECTOR	1
6	N458162	WARNING LABEL	1
7	5140181-14	LED ASSY	1
9	330019-00	SCREW,PLASTITE	3
10	N439616	STRAP	1
11	N442547	PLATE	1
12	330019-17	SCREW	2
13	N442546	RING	1
14	N438696	MACHINE SCREW	10
15	N436917	HOOK	1
16	330045-69	THREAD FORMING SCREW	1
17	5140181-11	GEAR KIT	1
25	DCE1501	MOVING BLADE	1
26	5140181-10	BOLT PACK	1
30	5140181-09	BACK TEETH	1
32	5140181-08	FRONT TEETH	1
35	5140181-06	MOTOR & PINION	1
47	5140181-07	TRANSMISSION ASSY.	1
50	5140181-12	FIXED BLADE ASSY.	1
51	N458163	ID LABEL	1
90	N463971	SHOULDER STRAP	1
101	000000-00	No Longer Available	1
112	5140181-15	COVER	1
113	5140181-16	WASHER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DCE150B Type 1

Item Number	Part Number	Description	Qty Required
118	5140181-17	GEAR CASE COVER	1
119	5140181-18	PLATE	1
120	5140181-19	SCREW	2
121	5140181-20	SCREW	9
122	5140181-21	PROTECTION PLATE	1
123	5140181-22	SCREW	1
124	5140181-23	ROLLER	2
137	5140181-24	SCREW	2
138	5140181-25	BOLT	2
139	5140181-26	PLATE	1
140	5140181-27	SCREW	5
141	5140181-28	FIXED BEARING	1
142	5140181-29	GEAR	1
143	5140181-30	COVER	1
144	5140181-31	COVER	1
861	N458052	KIT BOX	1
866	DCB203	BATTERY PACK	1
871	DCB115	CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.