



CYLINDERS

### CYLINDER LIFTING HANDLE

**No. 420655OR9** — Lifting handle for “C” series, 25 ton cylinders.

**No. 421312OR9** — Lifting handle for RH302, RH303, RH306 and RH306D cylinders.

**No. 252215** — Lifting handle RHA306, 30 ton cylinder.

**No. 420496BK2** — Lifting handle RA552 and RA554, 55 ton cylinders.

**No. 420498BK2** — Lifting handle RA1002, 100 ton cylinder.

### ALUMINUM CYLINDER BASE



**Aluminum Cylinder Base** – For use when an enlarged cylinder base is needed or advantageous. Attaches to bottom of RA556, RA556L and RA5510 with four  $\frac{3}{8}$ ”-16 screws (included). Serrated base for extra stability.

**No. 208406** – Aluminum cylinder base, 7” square. For use with RA556, RA556L and RA5510 cylinders.



Quick-Change Inserts

### HEAD INSERTS FOR RH SERIES CYLINDERS

For Use With:	Threaded Insert Order No.
RH102, RH108	28632 $\frac{3}{4}$ ”-16
RH203	28612 1”-8
RH302, RH306	38904 $1\frac{1}{4}$ ”-7
RH303	28644 $1\frac{1}{4}$ ”-7
RH503	38855 $1\frac{5}{8}$ ”-5 $\frac{1}{2}$
RH603, RH605 RH606	34251 $1\frac{5}{8}$ ”-5 $\frac{1}{2}$

### “QUICK CHANGE” HEAD INSERTS FOR RT SERIES CYLINDERS

For Use With:	Threaded Order No.*	Plain Order No.
RT172	21669	21714
RT302	21873	21872
RT503	22274	22275
RT1004	24197	24196

Switch from a tapped hole to a plain hole quickly with these cylinder head inserts. They are held in place with a socket screw. Plain hole permits use of a speed nut for re-adjusting cylinder after extension.

\* Provided with cylinder